X - Compatible

1 - FASST mode

2 - S-FHSS receiver is compatible with FHSS and S-FHSS

3 - R334SBS/-E receiver is compatible with T-FHSS and T-FHSS SR

			Receivers																																										
			Air																														Surface													
			FHSS	S-FHSS					T-FHSS						T-FHSS Mono	FASST/*FASST 7 Ch.											FASSTest					FHSS		S-FHSS			T-FHSS			T-FHSS SR		FASST C2		FASST C1	
			R2004GF	**R2006GS**	**R2008SB**	**R2106GF**	**R2001SB**	**R2000SBM**	**R3001SB**	**R3004SB**	**R3006SB**	**R3106GF**	**R3008SB**	**R3206SBM**	**R3106GF**	**R6004FF**	**R6008HS**	**R6014HS**	**R6106HF**	**R616FFM**	***R617FS**	**R6202SBW**	**R6203SB**	**R6208SB**	**R6303SB**	**R6303SBE**	**R7003SB**	**R7006SB**	**R7008SB**	**R7014SB**	**R7108SB**	**R603GF**	**R2004GF**	**R203GF**	**R204GF-E**	**R2104GF**	**R304SB**	**R304SB-E**	**R324SBS**	**R334SBS**	**R334SBS-E**	**R614FS**	**R614FF-E**	**R603FS**	**R603FF**
Transmitters	**Air**	**4YF**	X																																										
		6EX														X			X	X	X	X	X		X	X		1		1	1														
		6J	X	X	X	X	X	X																																					
		6K		X	X	X	X	X	X	X	X	X	X	X	X																														
		6L							X	X	X	X	X	X	X																														
		7C (2.4)														X			X	X	X	X	X		X	X		1		1	1														
		8FG/S														X	X	X	X	X	X	X	X	X	X	X		1		1	1														
		8J	X	X	X	X	X	X																																					
		10J		X	X	X	X	X	X	X	X	X	X	X	X																														
		12K		X	X	X	X	X	X	X	X	X	X	X	X																														
		14SG		X	X	X	X	X								X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X														
		16SZ		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X														
		18MZ		X	X	X	X	X								X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X														
		18MZ WC		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X														
		18SZ/(70th)		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X														
		32MZ		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X														
		TM8 Module														X	X	X	X	X	X	X	X	X	X	X																			
		TM10 Module														X	X	X	X	X	X	X	X	X	X	X																			
		TM14 Module														X	X	X	X	X	X	X	X	X	X	X																			
		TMFH Module		X	X	X	X	X																																					
	Surface	**3PRKA**																														X	X	2	2	2									
		3GR																																										X	X
		3PL																														X	X	2	2	2									
		3PM/X																																										X	X
		3PV																														X	X	X	X	X	X	X	X	3	3				
		4GRS																														X	X	X	X	X	X	X	X	3	3				
		4PK/S/R																																								X	X	X	X
		4PL																														X	X	X	X	X									
		4PLS																														X	X	X	X	X	X	X	X	3	3				
		4PM																																X	X	X	X	X	X	X	X				
		4PV																																X	X	X	X	X	X	3	3				
		4PX/(R*)																																X	X	X	X	X	X	3	3	X	X		
		7PX/(LE*)																																X	X	X	X	X	X	X	X	X	X		
		C1 Module																																										X	X