


# Futaba 32MZ Additional manual



## When setting wireless using CGY760R (Helicopter gyro)

### GPB-1 wireless transfer function

It is a function to transfer the data set in GPB-1 to CGY760R with the transmitter.

Gyro  
program box



GPB-1  
(Sold separately)



T32MZ



Flybarless gyro  
integrated receiver



CGY760R  
(Sold separately)

## Connection of T32MZ and GPB-1

Connect the T32MZ's **Trainer** connector to the GPB-1's **"Tx"** connector with the **Transmitter Connection Cable** supplied with the GPB-1.



Connect the T32MZ's **"S.I/F"** (S.BUS) connector to the GPB-1's **"Gx"** connector with the **CGY760R Connection Cable** supplied with the GPB-1.

\*While connecting the GPB-1, do not use the "S. BUS Servo" setting screen and the "Sensor" setting screen.

\*T32MZ does not support WTR-7 (wireless trainer).